## Power Information

KW - kilowatts

KVA - kilo volt-amperes

pf - power factor

KVAR - kilo volt-amperes reactive

$$KW = KVA \times pf$$
  $KVA = \frac{KW}{pf}$ 

of = 
$$\frac{KW}{KVA}$$
 KVAR =  $\sqrt{KVA^2 - KW^2}$ 

The KW rating of the engine-generator set is dependent on the horsepower rating of the prime mover and the elec trical rating of the generator. The KVA rating of the generator is dependent on the current rating of the generator.

## **Voltage Derating**

Load banks are designed to provide a specific capacity at a rated voltage.

They cannot be operated at a voltage higher than their rating without risking damage to the load bank. However, the load bank can be operated at lower voltages.

## Single-voltage Load bank derating is calculated as follows:

DxRated Capacity - Reduced Rating

#### Multi-voltage load bank derating is calculated as follows:

1. When applied voltage is higher than rated voltage +  $\sqrt{3}$ 

D x Rated Capacity = Reduced Rating

2. When applied voltage is lower than rated voltage  $\pm \sqrt{3}$ 

$$\frac{\text{Applied Voltage}^2}{(\text{Rated Voltage} + \sqrt{3})^2} = 0$$

Dx Rated Capacity = Reduced Rating







## Greenpower AB

Helsingborgsvägen Varalöv 262 96 Ängelholm, Sweden Tel: +46 431 222 40 E-mail: Info@greenpower.se web:www.greenpower.se





- 1, Resistive or inductive type of load, 304 Stainless steel sheathed elements manufactured from high grade nickel-chromium alloys resistive wire covered by 3-year warranty.
- 2. Rated testing voltage: AC 3P4W<sub>c</sub> 110-690 VAC 50/60HZ.
- 3. Cooling mode: forced air-cooled, vertical or horizontal discharge. External utility power or generator power supply for fans.
- 4. Working mode: load step control. Total testing capacity ranges from 0kw to the max consisting of 10kw, 20kw, 50kw, 100kw load setting switches plus a 0-10kw fine-tuning knob. From 0kw to the max, any load combination is achievable.
- 5. Load bank features world-famous components to ensure reliable performance and longer service life including: contactors. SIEMENS switches, knobs and indicators.

circuit breakers.

OmROn intermediate relays.

MPHCENIX LYCONTACT terminal blocks.

- 6. Parameter measuring accuracy grade: 0.5.
- 7. Load control accuracy: ±3%.
- 8. Load bank protections: over heating protection, cooling fans failure protection and over load protection with alarm.
- 9. Control mode: two control modes available: a) Local manual control; b) Optional: Manual control via a remote control panel (max control distance is 20m).1
- electric Multifunction Electricity Meter displaying voltage, 10. Parameter display and measurement: Control panel contains a current, load power, reactive power, apparent power, power factor, frequency etc. (Optional: a professional generator tester displays and measures all sorts of steady, dynamic parameters as well as harmonic wave, can be connected to a PC for data recording and test report printing)."
- 11. Operating environment: Altitude: ∧3000m above sea level. Ambient temp: -10 ℃ ~+50 ℃ Relative humidity: <80% ventilated environment without explosive or corrosive dust. Not allowed to use in rainy outdoor environment."



# Green Power®

## Routine Maintenance of Generators with Load

Eliminate wet-stacking Find out the aging spare parts Troubleshooting for generator

Generatorinstalledovera Year Generator repaired

Test its actual load capacity

Generator after Silencing

Test if the actual output is affected


Newly Installed Generator

Projects acceptance
Test if the power output is as rated






- Generator Set
- UPS Systems
- Battery Banks
- Military Power Supply
- Weapon Power Supply System
- Aircraft Power Source
- New Energy Power Source



- Vessel & Offshore Platform
- Oil, Mining, and Metallurgy
- Military & Aerospace
- Data center, Telecom & Communication Operators
- Power Plant, Nuclear Power Plant
- Medical System
- Railway
- Research Institute, University & Schools



3








Measurement	Range	Accuracy	Resolution	Overload
Voltage (V)	10.0500.0V	± (0.4% reading+0.1%range)	0.1V	600V
Current (A)	0.030 5.000A	± (0.4% reading+0.1%range)	0.001A	6A
		Power factor=1.0	<200W 0.1W	
	According to volt	± (0.4% reading+0.1% range)	∧200W 1W	
Power	range & current range	Power factor=0.5		
		± (0.8% reading+0.2% range)		
Power factor	0.201.00	±0.02	0.001	
Frequency	45 65Hz	±0.2Hz	0.01 Hz	
Running time	99h59m	±2min/hour	1 minute	
		Power factor=1.0		
"Energy (kWh)"	99999kWh	± (0.4% reading+0.1% range)	0.001kwh	
		Power factor=0.5		
		± (0.8% reading+0.2% range)		
Harmonic analysis (%)	2-50 times and total harmonic			





CONTROL PANEL






Your Generator Safeguard.



Copper bars and heat-resistant wires



304 stainless steel sheathed resistors



Resistors tested to the core




Schneider contactors


Green	Power

## Test report of generator set's steady performance

				CSI	ıe	pui	t Oi ţ	gene	51 a	iloi .	SCI	133	iCo	auy	he	:110	1111	arice	,		
IS0852	28 GB2	820-200	9												Date	e of test	: 20	12-11-15	test tim	e: 1	7:36:28
(A) tec	hnica	specifi	cation																		
1:Set t	уре	K1	109A	Set NC	<b>)</b> .	K110	9A1007	Item N	Ο.		Se	et Pr:			ı	oowerf	actor	1	power fa	actor	
Rated	freque	ncy 60	ΗZ	rate Ur	:	127/2	220V	rate Ir:			Ite	em na	me								
2:engi	netype	i i		Engine	e NO.			certific	ate			v foot	oni		ç	govern	or		governo	r	
3:gene	3:generator type K1109A Gen NO		IO.	K1109A1007					ex-factory date		1		6	excitati	on		excitation				
(B) che	ck iten	1																			
	ive hun				529	%	enviro	nmental	temp	erature	2	22 :	atmos	sphere	e: k	Pa e	exam	ine the e	xterior o	f gene	rator set:
		ation res ature a				mea	asure ex	citation	windir	ng grou	nding	ginsul	ation i	esista	nce			insulation ry excit w			
	insu	lation di	electri	0		phase	sequer	nce					chec	k start į	perfor	mance	atno	rmal tem	perature	start 3	times)
3:che	ck ever	y indicat	ion eq	uipme	nt's w	ork co	ndition	of contro	Iscre	en											
	indi	catingir	strum	ent		check	oversp	eed stop	p h	igh wat	ter ter	mpera	ature				est of	high cylin	ders tem	peratur	е
low oil	pressur	eproted	tion			check	emerg	ency sto	p c	heckb	attery	y char	ging								
(C) Lo	ad test																				
load	powei	· v	oltage	(V)		cur	rent(A)		stead		uenc	yFI	stea volta		stea reque	~ J.		adjustment ange		adjustme	nt voltage modulatio
%	(KW)	UA	UB	UC	;	IA	IB	1C	facto		(Hz)		deviation				rise	fall	rise	fall	^Umod,s
0%	0.000	221.1	222.	3 221	.4 0	.000	0.000	0.000	0.00	0	60.33	3			0.5	5	1.03	-0.45	0.85	-0.3	2 1.55
25%	20.51	221.6	222.	1 221	.5 5	3.50	53.29	53.33	1.000	0	60.34	4			0.3	5	1.08	-0.46	0.85	-0.23	3 0.77
50%	40.64	222.3	221.	7 221	.7 1	05.72	106.02	105.56	1.000	0	60.28	3			0.7	8	75.23	-74.03	1.17	0.05	1.39
75%	61.12	221.8	222.	2 222	.0 1	59.24	159.34	158.76	1.000	0	60.23	3			0.5	8	75.18	-74.35	0.97	-0.18	3 1.53
100%	90.90	221.7	221.	6 221	.6 2	36.96	237.42	236.39	1.000	0	60.36	6			1.2	3	75.28	-73.77	1.03	-0.12	2 1.54
110%	87.88	221.8	221.	3 221	.7 2	29.06	229.45	228.35	1.000	0	60.38	3			0.9		75.1	-73.79	1.08	-0.08	3 1.23
100%	80.58	221.7	221.	5 221	.5 2	10.36	210.70	209.46	1.000	0	60.44	4			1.4	3	75.5	-74.0	1.15	-0.03	3 1.39
75%	60.75	221.8	222.	2 221	.6 1	58.33	158.39	157.86	1.000	0	60.44	4			0.7	8	75.25	-74.13	1.05	-0.12	2 1.69
50%	40.71	221.7	222.	0 222	.0 1	05.89	106.26	105.92	1.000	0	60.36	5			0.9	7	75.44	-74.11	1.05	-0.08	3 1.23
25%	19.96	221.9	222.	1 221	.0 5	2.12	52.70	51.92	1.000	0	60.13	3			0.7	8	74.9	-74.12	1.03	-0.2	0.77
0%		221.7				-			0.000	-	60.26				0.6	5	74.79	-73.97	1.0	-0.2	1.24
test result		voltage				0.2		steady				on  ÂF	%:	1.43 0.55		voltage		e form te Ku%;	0.00%	Ġ.	
		den on(c			Ju,3 /0	, I.C	,,,	nequei	ioy iai	ii ; Al 31/				0.00		uisiora	Joilla	io Nu /o.			
		*	•	(Load	Sudd	len on	Ť	Freque	ncv(L	oad Su	dden	on)	,	Voltag	e(Loa	d Sudd	en off	Fre	equency(L	oad Su	idden off)
transie	ent t		_	mentr		,	time tr		djustr			time	transi	_	justme	ent ste	,	me transi		tment	steady time 0.58s
conclu	usion					teste	r:			ecker:	1	exar	miner			siç	gnatu	re:			


#### **SPECIFICATIONS**








## Loaa Trequency CUIVE








#### Load current curve



#### Unload current curve



Load bank is a simulating load test equipment used for generators, UPS, battery banks etc power systems testing.

- (1) Routine load test prolongs the service life of standby generators by minimizing their chances of suffering from wet stacking, cylinder glazing, fouling of exhausf ports and excessive oiling.
- (2) Used for standby generators routine maintenance or functional test to avoid cutting off the mains supply for the whole power system.
- (3) Using load bank for standby generators maintenance or functional test effectively reduces the risk of the powered devices being damaged by the potentially malfunctioning generator.

## Applications:

- (1) Generator system R & D and routine test (inspection).
- (2)Standby generator routine maintenance load test.
- (3)Acceptance test for power supply project.
- (4)UPS products R & D, routine test and maintenance.
- (5)Load profile optimization test for electric power supply system.

## Operation steps:

- 1) Make sure the load bank is properly grounded before any operation.
- 2)Connect the load bank and tested generator with suitable size cables according to the power capacity of the tested generator.
- 3)Select the corresponding load testing voltage according to the actual rated voltage of the tested generator.
- 4)Connect mains input socket next to the bus-bars of the load bank with mains power if mains power is chosen as load bank control power.
- 5) Flip either the MAINS or GENSET circuit breakers on load bank control panel to "ON" according to your selection of control power, flip the POWER SELECTOR switch to either MAINS or GENSET position as per your selection.
- 6)Flip the "CONTROL MODE" switch on load bank control panel to "LOCAL".
- 7)Start the generator until the voltage and frequency reach their rated values and stay steady, then flip the circuit breaker on generator to "ON".
- 8)Press the button on PHASE SEQUENCE INDICATOR on control panel, observe the rotating direction of the pointer and make sure it's clock-wise. Otherwise, it means there's mistake in phase sequence amongst the cables connecting load bank to generator; or the internal phase sequence in the generator is wrong. Solve this problem first before proceeding load test.

### **TEST YOUR GENERATORS**



9) Turn on the FAN switch on control panel to start the cooling fans.

10)Turn on the MASTER LOAD switch.

11)Turn on the FINE-TUNING switch.

12)Increase the load gradually by turning on the load setting switches (interval between every increase should be 10s), also use the knob for 0-10kw fine-tuning until the load reaches the rated power of the generator. Note: load can not be added unless the fans have been started and the MASTER LOAD switch has been turned on.

13)When test is over, disconnect the load by turning off load setting switches from bigger ones to smaller ones until all loads are disconnected. (Interval should be 10s as well)

14)Keep the fans running for another 10-15 minutes until the discharged air cools down, then switch off the fans. (This step is critical for load bank's service life)

15) Flip the circuit breaker on control panel to "OFF" when the fans stop rotating.

#### **IMPORTANT NOTES:**

- 1)When the load bank is running, no one is allowed to walkthrough nor flammable materials such as gasoline, diesel should be placed within 10m extent of the exhaust end.
- 2)When the load bank is running, people with long hair are not allowed to walk through within 1 m extent of the air intake end.
- 3)The airflow direction of the load bank is from air intake end to exhaust end. When the fans start running, make sure the airflow direction is correct, otherwise, you'll need to adjust the phase sequence of the input mains power or the testing power.





Picture									
Model	KPLB-100	KPLB-200	KPLB-300	KPLB-400					
Testing capacity	0 - 100 kw	0 - 200 kw	0 - 300 kw	0 - 400 kw					
Type of load	Resistive, PF = 1.0								
Duty		Continuous							
Cooling system		Industrial grade axial fan							
Phase	Available at both single and three phase								
Rated testing voltage	110-480 VAC								
Rated Frequency	50/60 Hz								
Dimensions (L*W*H) (mm)	960*1060*1400	1560*1310*1650	1690*1440*1750 1900*1600						
Weight	350 Kg	500 kg	1083 kg	1200 kg					

Picture									
Model	KPLB-500	KPLB-600	KPLB-700	KPLB-800	KPLB-1000	KPLB-2000			
Testing capacity	0 - 500 kw	0 - 600 kw	0 - 700 kw	0 - 800 kw	0 - 1000 kw	0 - 2000 kw			
Type of load	Resistive, PF = 1.0								
Duty	Continuous								
Cooling system	Industrial grade axial fan								
Phase	Available at both single and three phase								
Rated testing voltage	110-480 VAC								
Rated Frequency	50/60 Hz								
Dimensions (L*W*H) (mm)	1900*1600*1900	2100*1730*2000	2100*1730*2000	2400*2030*2100	2400*2030*2100	20 ft container			
Weight	1400 kg	1550 kg	1650 kg	1750 kg	2150 kg	6000 kg			

## Options:

1. Single-voltage: 220-690V

2. Multi-voltage:127/220V, 220/380V, 230/400V, 240/415V, 277/480V

3. Intelligent control with PLC



Picture									
Model	KPLB-125	KPLB-250	KPLB-375	KPLB-500					
Testing capacity	0 - 125 KVA	0 - 250 KVA	0 - 375 KVA	0 - 500 KVA					
Type of load	Inductive and resistive, PF = 0.8-1.0								
Duty	Continuous								
Cooling system	Industrial grade axial fan								
Phase	Available at both single and three phase								
Rated testing voltage	110-480 VAC								
Rated Frequency	50/60 Hz								
Dimensions (L*W*H) (mm)	960*1060*1400	1560*1310*1650	0*1650 1690*1440*1750 1900*1600*19						
Weight	770 Kg	1100 kg	1100 kg 1700 kg						

Picture								
Model	KPLB-625	KPLB-750	KPLB-875	KPLB-1000	KPLB-1250	KPLB-2500		
Testing capacity	0 - 625 KVA	0 - 750 KVA	0 - 875 KVA	0 - 1000 KVA	0 - 1250 KVA	0 - 2500 KVA		
Type of load	Inductive and resistive, PF = 0.8-1.0							
Duty	Continuous							
Cooling system	Industrial grade axial fan							
Phase	Available at both single and three phase							
Rated testing voltage			110-480 VAC					
Rated Frequency	50/60 Hz							
Dimensions (L*W*H) (mm)	1900*1600*1900	2100*1730*2000	2100*1730*2000	2400*2030*2100	2400*2030*2100	20 ft container		
Weight	3200 kg	3600 kg	4000 kg	4730 kg	5000 kg	13200 kg		

- 4. Remote control or monitoring via RS485 or Ethernet
- 5. Trailer mounted
- 6. 2000 5000kW on request